

PercoTop® 2K Fedőfestékek



| | | Térfogat | | Súly | | Fényesség (60° mellett) | |
|--|--|---|----------------------|------|--|--|--|
| PercoTop® PUR 2K MS Topcoat | PCTPUR CS920: PercoTop® 2K PUR Binder CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS704 PercoTop® 3840 | 5:1 | 5:1 | CS600 PercoTop® Thinner Standard CS602 PercoTop® Thinner 2K CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS603 PercoTop® Thinner Fast | high gloss: glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| | | CS 701 PercoTop® Activator Standard | 2:1 | 2:1 | | | |
| PercoTop® PUR MATT 2K MS Topcoat | CS923: PercoTop® 2K PUR MATT Binder CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS704 PercoTop® 3840 | 6:1 | 7:1 | CS600 PercoTop® Thinner Standard CS602 PercoTop® Thinner 2K CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS603 PercoTop® Thinner Fast | dead matte: | 3-25 GE |
| | | CS 701 PercoTop® Activator Standard | 3:1 | 5:2 | | | |
| PercoTop® 449 2K Structure Topcoat | PCT449STR CS949: PercoTop® 2K Structure Binder CS944: PercoTop® 2K Matt Structure Binder CS209: PercoTop® Gloss Agent 2K# CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow CS704 PercoTop® Activator 3840 (Fast) Optional: CS706 PercoTop® Activator 4060 (indoor) | 4:1 | 5:1 | CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS602 PercoTop® Thinner 2K | high gloss glossy semi-gloss semi-matte matte | |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow CS704 PercoTop® Activator 3840 (Fast) Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 4:1 | 5:1 | CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS602 PercoTop® Thinner 2K | semi-matte | |
| PercoTop® 611 2K DTM Topcoat | PCT611DTM CS911: PercoTop® 2K DTM Binder CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow CS704 PercoTop® Activator 3840 (Fast) Optional: CS706 PercoTop® Activator 4060 (indoor) | 9:1 | 10:1 | CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS603 PercoTop® Thinner Fast | high gloss: glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow CS704 PercoTop® Activator 3840 (Fast) Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 9:1 | 10:1 | CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast | glossy | |
| PercoTop® 617 2K DTM Fast-drying Topcoat | CS956: PercoTop® 1K Acrylic Binder CS911: PercoTop® 2K DTM Binder CS203: PercoTop® Matting Agent DTM CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS721 PercoTop® Activator MS Fast CS722 PercoTop® Activator MS Slow | 4:1 | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 4:1 | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| PercoTop® 9600 2K MS Topcoat | PCT9600 CS960: PercoTop® 2K MS Binder 9600 CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS721 PercoTop® Activator MS Fast CS722 PercoTop® Activator MS Slow | 4:1 | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 4:1 | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss: glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| PercoTop® 771 2K HS All-Round Topcoat | PCT771 CS905: PercoTop® 2K HS Binder CS909: PercoTop® 2K HS Matt Binder CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 4:1 | 5:1 | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss: glossy: semi-gloss: semi-matte: matte: very matte: dead matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE 10-25 GE 3-10 GE |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 4:1 | 5:1 | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss: glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| PercoTop® HS 2K HS Topcoat | PCTHS CS905: PercoTop® 2K HS Binder CS909: PercoTop® 2K HS Matt Binder CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow CS640 PercoTop® Thinner Extra Slow | high gloss: glossy: semi-gloss: semi-matte: matte: | 85-98 GE 70-85 GE 55-70 GE 40-55 GE 25-40 GE |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow Optional: CS702 PercoTop® Activator Fast CS706 PercoTop® Activator 4060 (indoor) | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| PercoTop® 9675 2K HS Topcoat | PCT9675 CS975: PercoTop® 2K HS Binder 9675 CS979: PercoTop® 2K HS Matt Binder CV CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| PercoTop® 9700 2K HS Topcoat | PCT9700 CS970: PercoTop® 2K HS Binder 9700 CS0XX: Tints | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast | 3:1 Std. 5:1 Matt | - | CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard CS630 PercoTop® Thinner Slow Optional: CS640 PercoTop® Thinner Extra Slow | high gloss semi-gloss semi-matte matte | |
| PercoTop® EP 2K Epoxy Topcoat | PCTEP CS980: PercoTop® 2K Epoxy Binder CS201: PercoTop® Matting Agent 1K CS0XX: Tints | CS780 PercoTop® Activator Epoxy | 5:1 | 7:1 | CS680 PercoTop® Thinner Epoxy | high-gloss: glossy: semi-gloss: | 75-90 GE 65-75 GE 45-60 GE |
| | | CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard Optional: CS702 PercoTop® Activator Fast CS703 PercoTop® Activator UV-Resistance CS704 PercoTop® Activator 3840 (outdoor) CS705 PercoTop® Activator 4040 (indoor) | 7:1 | 10:1 | CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast CS620 PercoTop® Thinner Standard Optional: CS602 PercoTop® Thinner 2K CS603 PercoTop® Thinner Fast | semi-gloss | |