

Percotop® 2K Alapozók



			Térfogat	Súly
PercoTop® 2K High Chromate Wash Primer	CS307: ochre	CS737 PercoTop® Activator Wash Primer High Chromate	1:1	-
PercoTop® 2K Chromate-Free Wash Primer	CS305: olive grey	CS709 PercoTop® Activator Wash Primer	1:1	-
PercoTop® 2K Filling Wash Primer	CS308: yellowish	CS709 PercoTop® Activator Wash Primer	2:1	-
PercoTop® 2K HS Primer 040	CS340: light grey CS342: white CS343: black CS345: Binder	CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS704 PercoTop® Activator 3840 (Fast) Optional: CS705 PercoTop® Activator 4040 CS706 PercoTop® Activator 4060	9:1	10:1
		Optional: CS714 PercoTop® Activator 3845 CS726 PercoTop® Activator 4065	4:1	5:1
PercoTop® 2K HS Primer 049	CS391: grey CS392: ivory	CS705 PercoTop® Activator 4040 CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard Optional: CS704 PercoTop® Activator 3840 (Fast) CS706 PercoTop® Activator 4060	9:1	10:1
		CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast Optional: CS714 PercoTop® Activator 3845 CS726 PercoTop® Activator 4065	5:1	6:1
		CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast	4:1	5:1
PercoTop® 2K VHS Power Primer 4000	CS371: pearl white CS372: dark grey	CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow For 2K mixing equipment: CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast	8:1	12:1
		CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow CS717 PercoTop® Activator HS Extra Slow CS718 PercoTop® Activator HS Slow CS719 PercoTop® Activator HS Standard CS720 PercoTop® Activator HS Fast	5:1	8:1
PercoTop® 2K Express Sanding Surfacer	CS354: black	CS710 PercoTop® Activator VHS Fast CS711 PercoTop® Activator VHS Standard CS712 PercoTop® Activator VHS Slow	7:1	100:11
PercoTop® Clear Carbon Fibre Sealer	CS399: transparent	CS703 PercoTop® Activator UV-Resistance	4:1	4:1
PercoTop® 2K Epoxy Primer	CS381: light grey CS381B: black CS381W: white	CS781 PercoTop® Activator Epoxy Primer	5:1	9:1
PercoTop® 2K Zinc Rich Epoxy Primer 053	CS382: grey	CS788 PercoTop® Activator Epoxy	5:1	15:1
PercoTop® MIO Epoxy Coating	CS581: DB 702 light grey	CS571 PercoTop® Activator Special Epoxy	3:1	6:1
PercoTop® Epoxy ZP High Build Coating	CS582: ca. RAL 1002 sand yellow	CS571 PercoTop® Activator Special Epoxy	4:1	7:1
PercoTop® Epoxy HS High Build Coating	CS591: ca. RAL 7001 silver grey	CS571 PercoTop® Activator Special Epoxy	4:1	100:17

Percotop® 1K Alapozók

			Térfogat	Súly
PercoTop® 1K Primer 010	CS310: light grey CS312: white CS313: black CS315: Binder	-	-	CS600 PercoTop® Thinner Standard Optional: CS610 PercoTop® Thinner Fast
PercoTop® 1K Primer 021	CS321: light grey	-	-	CS600 PercoTop® Thinner Standard CS610 PercoTop® Thinner Fast
PercoTop® 1K Welding Primer	CS314: red brown	-	-	-

Percotop® Kittek

			Térfogat	Súly
PercoTop® Putty	CS160: beige	CS760 PercoTop® Activator Putty Standard Red CS763 PercoTop® Activator Putty Slow Blue	-	100:2-3
PercoTop® Sprayable Putty	CS161: grey beige	CS761 PercoTop® Activator Spray Putty	100:5	100:3,5
PercoTop® High Temperature Putty	CS162: grey	CHP-Hardener-Paste yellow paste (Artikenummer 1250087197)	-	100:2
PercoTop® Thixoflex Putty	CS165: beige	CS760 PercoTop® Activator Putty Standard Red	-	100:2-3
PercoTop® Fine Fairing Putty	CS166: beige	CS760 PercoTop® Activator Putty Standard Red CS763 PercoTop® Activator Putty Slow Blue	-	100:2-3